



RESNET

**SAVE UP TO 20% ON HVAC ENERGY COSTS
BY AIR SEALING & INSULATING YOUR HOME.¹**

Start your air sealing project by insulating your whole house fan, knee wall doors, attic access hatch, and/or disappearing stairway.


Start Saving Today on Your Electric and Gas Bills!!!

Seal A Fan™ Model (ES-SAF - I) Patent Pending

Fits most manufacturers 24 inch and 30 inch blade fans which include Triangle Engineering, Master Flow Fans.

Fits Air Vent and Dayton direct drive fans only. Custom Sizes Available

ARE YOU WASTING MONEY?



Typical HVAC Energy Savings 5%--10%

**Installs in Minutes
Green Building Product
Multi-Layer Closed Cell Insulation**

Effective R-Value 13 97% Radiant Heat Reflective

Noise Barrier Sound Reduction

Class A/Class 1 Fire Rated


Code Compliant

Virtually Eliminates Drafty Attic Fan Openings

¹http://www.energystar.gov/index.cfm?c=home_sealing.hm_improvement_sealing

INSTALLATION INSTRUCTIONS WHOLE HOUSE FAN COVER

1. Unpack the contents of your new whole house fan kit.
2. Check to ensure that the following items are included in your installation kit:
 - (1) Top piece
 - (1) Perimeter Wall
 - (2) Pieces of Foil Tape
3. Measure dimension A, the width of your ventilation fan base.



4. If your fan base is **34 inches**, proceed to step six.
5. If your fan base is **28 inches**, follow the instructions according to Figure I (Next Page) **prior** to proceeding to step six.
6. If there is an electrical wire supplying the fan located on the outside of the fan base, secure the electrical wire to the frame with tape or a strap.
7. Clean the fan base with a dry cloth and apply a bead of caulking about 1 inch above the bottom of the fan base on all four sides.

PERIMETER WALL


8. During installation of the perimeter wall, install a **staple every 8 to 10 inches in the wood frame** to hold the wall in place. (AVOID STAPLING CLOSE TO THE ELECTRIC WIRE THAT SUPPLIES THE FAN WITH POWER) Start at one corner of the fan frame and wrap the perimeter wall (long piece) completely around the fan base on all sides with the hook & loop fastener strip located at the

INSTALLATION INSTRUCTIONS WHOLE HOUSE FAN COVER

- top **facing outward** away from the fan. Trim the extra material even with the corner where the two ends of the perimeter wall meet so both end pieces fit together. Discard the remainder of the material. Make sure the perimeter wall covers the caulking on all four sides. Seal the electrical power wire with caulking where it exits from the cover after installation.
9. Join the two ends of the perimeter wall at the original corner where you started and seal with two pieces of the foil tape provided. Install the foil tape on the outside and inside of the corner where the two ends of the perimeter wall meet. Do not apply the outside piece of foil tape over the hook & loop fastener strip.
 10. Install the top on the perimeter wall attaching the outside edges to the top of the perimeter wall while pressing lightly on the hook & loop to secure both pieces together.

FIGURE I **CUTTING INSTRUCTIONS FOR 28 INCH FAN COVERS**

1. Cut the insulated cover top with a pair of scissors along the bold line indicated for a 28-inch top and discard the remainder of the material.



2. Once you have cut the top panel to the proper size, return to step 6 to complete the installation of your new insulated fan cover.